



HUO 510


Wiring diagram – cab (1)



HUO 510
Wiring diagram – cab (2)



HUO 510 - Boot wiring



Boot cable runs and junction boxes



C1x4 – cable 1, 4 cores. L1x7 – loom 1, 7 cores. L1ax5 – loom main branch from L1 with 5 cores. L(R)CS – left/right combined S&T. R(R)LI – Rear Left/Right indicator lamp assy. S – single stop light. T – single tail light